

Primatech P240 PNEUMATIC NAILER

Guide for Replacement Parts



Compatibility issues:

Feb 2007 A new valve assembly was introduced on some models. It uses a *snap-on* design to assemble the actuator components together. Check if your valve assembly uses screw P-544B and check below to order the correct replacement part. See [note](#) for more details.

Part Number	Description	Notes
P-005	Cap screw and washers	
P-009	Rectangular ring	
P-014	O-Ring	
P-015	Socket cap screws	
P-017	Plug	
P-024	Spring washer for driving blade	replaces the old block; now included with replacement driving blades; see note .
P-034	Screw & washer	
P-046	Spring & clip for channel	
P-051	"7" Channel	
P-054	Self-adhesive handle grip	see also P-154.
P-055	Pressure valve	see note .
P-080	2.8 LBS hammer	
P-084	Rubber cap (white)	see instructions .
P-087	Reinforcement block	
P-090	Non-detergent oil (250ml)	
P-107	Gasket	see instructions .
P-125	Bumper	see note .
P-128	Hex cap screws	
P-148	Standard "L" channel	
P-149	18" - 200 cleats "L" optional channel	
P-154	Handle grip	for tools manufactured after Sept 2005; see instructions .
P-188	Adapter for 1/2" solid wood	see Technical Note .

P-223	Driving blade with screw	see instructions .
P-226	Reinforcement plate with bushing	
P-227	Dowel pins	
P-235	Base	
P-261	Safety assembly	
P-262	Safety element	
P-285	Optional "T" gate	
P-288	Plastic base for <i>metric</i> floorings	includes shims and P-986 self-adhesive base.
P-329	Foot	
P-433	Plastic base	plastic base P-288 comes standard in some countries.
P-501	Head cap	for <i>screw-mount</i> valve.
P-506	Head	
P-516	Main body	
P-516B	O-Ring	
P-518	Cylinder	
P-518B	Cylinder band-valve	
P-522	Main piston	
P-522A	Piston ring	
P-522B	O-Ring	
P-541	Actuator head	for <i>screw-mount</i> valve; see note .
P-541A	O-Ring	discontinued, order P-541B.
P-541B	Plastic washer	for all actuator head P-541, see note .
P-542	Actuator	for <i>screw-mount</i> valve.
P-542A	Wear-ring	
P-543	Main valve	
P-544	Actuator cap	for <i>screw-mount</i> valve.
P-544B	Screw	for <i>screw-mount</i> valve.
P-601	Head Cap	for <i>snap-on</i> valve.
P-632	"L" Gate	
P-632B	Alternate "L" Gate	do not require block P-087.
P-642	Actuator	for <i>snap-on</i> valve.
P-644	Actuator cap	for <i>snap-on</i> valve.
P-986	Self-adhesive base	for use with 33/32" flooring.